

Designed by GUBI OLSEN

PRODUCT



Item no.: 30001-01-xx
+ style code

DESCRIPTION

The Gubi Olsen Collection counts a wide range of lounge and seating furniture, The Diva Daybed from 1982, the Grand Piano from 1986 and the Bonaparte series and Inuit, both from 1990.

The three-person sofa/chaiselong is available in right- and leftwards. The Sofa is produced in a solid beech frame covered with foam. The fabric is mounted on the frame. The seat cushion is removable and reversible. The legs are conical in black stained oak or light oak.

VERSION

- Fully upholstered /mat lacquered oak - leftwards
- Fully upholstered /black stained oak - leftwards
- Fully upholstered /mat lacquered oak - rightwards
- Fully upholstered /black stained oak - rightwards

TYPES

Order item - look for part number in the pricelist.
The series consists of the following:

GRAND PIANO SOFA



rightwards



leftwards

FACTS

MEASUREMENT

- Sitting height: 435 mm
- Sitting depth: 600mm
- Sofa height: 920 mm
- Sofa width: 2150 mm
- Sofa depth: 720 mm

WEIGHT ITEM

70 kg

PACKAGING TYPE

Cardboard box, chipboard and euro Pallet

PACKAGING MEASUREMENT - L X W X H CM

L: 240 X W:80 X H:85 CM

PACKAGING - MATERIAL TYPE


- Delivery note
- Cardboard box, FEFCO quality EB85BB
- Polybag PE
- Bubble wrap
- Strapping
- Chipboard and euro Pallet

WEIGHT PACKAGING - TOTAL

80 kg

NUMBER OF PARCELS

1 pcs.



CLEANING AND MAINTENANCE

Upholstery W x L
Fabric: 140 cm x 7,9 m

For cleaning the upholstered surface, first try to brush off the dirt gently. If this is not enough then vacuum the surface.

If further cleaning of the padding is needed, a stain remover is recommended. The cleaning has to be gentle and must always be tested on the most invisible area of the surface before the actual cleaning. Avoid blotches by gentle, circular rubbing towards the stain.

To avoid stains, quickly remove the dirt with a piece of absorbing household wipe and clean with water and colourless washing-up liquid.

Do not use the following products for the padding:

- Undiluted cleaning liquids.
- Bleach.
- Ammoniac.
- Soap for hard surfaces.

For dusting and light cleaning of the wooden surface and frame use a soft, dry cloth.

For further cleaning, use a soft cloth that is firmly wrung in clean water for gently wiping the surface, and then immediately use a dry cloth to wipe the surface again.

If more thorough cleaning is necessary, use a mild detergent or washing-up liquid dissolved in water on a firmly wrung cloth. Afterwards, repeat the process with clean water as described above.

Polish with a soft cloth after wiping.

Do not use materials for maintenance that:

- Contain abrasive agents.
- Are basic, acidiferous or organic.

For the best maintenance of the product, protect it against sunlight and heat, and try to keep it away from moisture, grease and other dirt.

Furthermore, protect the surfaces against sharp objects and other that might scratch.

ENVIRONMENT

Parts can be separated and sorted for recycling.

TESTS

-

CERTIFICATION AND LABELS

-